

INSTRUCTION GUIDE

- ① To insert the shank inside the concave area's well of the anchor
- ② With a screwdriver to push the shank forward in the well in order to get the holes in line
- ③ To insert the screw (if necessary to hammer the screw) and to tighten the nut firmly

Always use a new nylock nut each time it is opened



WARNING !!!

